

# Product Specification

## Senseair K33 ICB

Sensor for bio applications



### General

Senseair K33 ICB is targeted on bio applications with required measurement range 0 to up to 30%<sub>vol</sub>CO<sub>2</sub>. This document contains description of default appearance of Senseair K33 ICB.

The sensor is built on the Senseair K33 platform. This platform is designed to be a low power OEM module for built-in applications in a host apparatus or/and as a stand-alone CO<sub>2</sub> transmitter/switch module. Hence should be optimised for its tasks during a dialog between Senseair and the OEM customer. This document is to be considered as the starting point for such a dialog. One can find extra ideas on connection and use of Senseair K33 platform in platform description.

Senseair K33 ICB has the same dimension and attachment points as K30 platform based sensor.

## Terminal description

The table below specifies terminals and I/O options available in the general K33 platform (see also the alternative connection pictures below).

Functional group	Descriptions and ratings
<b>Power supply (all connection alternatives)</b>	
G+ referred to G0	Power supply plus terminal Protected by series 3.3R resistor and zener diode Absolute maximum ratings 5 – 14V, stabilised to within 10%
G0	Power supply minus terminal Sensor's reference (ground) terminal
DVCC = 3.3V	Output from sensor's digital voltage regulator. Series resistance 10R Available current 12mA Voltage tolerance (unloaded) $\pm 3\%$ max ( $\pm 0.75\%$ typ) Output may be used to power circuit (microcontroller) in host system or to power logical level converter if master processor runs at 5V supply voltage.
<b>Communication</b>	
UART (UART_TxD, UART_RxD)	CMOS physical layer, Modbus communication protocol. (refer TDE2336 "Modbus on Senseair K33 and eSENSE").  UART_RxD line is configured as digital input. Input high level is 2.1V min Input low level is 0.8V max  UART_TxD line is configured as digital output. Output high level is 2.3V (assuming 3.3VDVCC) min. Output low level is 0.75V max  UART_RxD input is pulled up to DVCC = 3.3V by 56kOhm UART_TxD output is pulled up to DVCC = 3.3V by 56kOhm  <b>ABSOLUTE MAX RATING</b> <b>G0 -0.5V</b> ..... <b>DVCC + 0.5V</b>
I2C extension. (I2C_SCL, I2C_SDA)	Pull-up to DVCC = 3.3V. (refer "I2C comm guide rev2_00 DRAFT.pdf" or later version for details)  <b>ABSOLUTE MAX RATING</b> <b>G0-0.5V</b> ..... <b>DVCC + 0.5V</b>

Table 1. I/O notations used in this document for the K33 platform with some descriptions and ratings (continued on next page).

NOTE! the **bolded texts that pinpoint important features** for the system integration!






Figure 3. Senseair K33 ICB OBA side)  
 (G+, GND, OUT1 and OUT2,  
 5.08mm hole spacing




Figure 4. Senseair K33 ICB (OBA side)  
 G+, GND, OUT1 and OUT2,  
 2.54mm hole spacing

## Ground / Shield attachments

Both Analogue ground (AGND) and digital ground (DGND) are connected internally to the G0 terminal of the sensor. AGND is connected to the most sensitive analogue part of the sensor and DGND is connected to the digital part of the sensor.

Do NOT connect AGND and DGND together externally to sensor!




Figure 5. Senseair K33 ICB ground / shield attachment

## Maintenance

Since the ABC algorithm cannot be used in all applications it is disabled in the sensors default appearance. When used in environments where the built-in self-correcting ABC algorithm can be enabled the Senseair K33 ICB is basically maintenance free.

Discuss your application with Senseair in order to get advice for a proper calibration strategy.

When checking the sensor accuracy, NOTE that the sensor accuracy is defined at continuous operation with enabled ABC algorithm (at least three (3) ABC periods after installation) or after zero/background calibration.

# Calibration

Default: ABC Off

When enabled the **ABC algorithm** (Automatic Baseline Correction) constantly keeps track of the lowest reading of the sensor over an ABC period (7.5 days interval) and slowly corrects for any long-term drift detected as compared to the expected fresh air value of 0.04%<sub>vol</sub> CO<sub>2</sub>.

Rough handling and transportation might result in a reduction of sensor reading accuracy. If the ABC algorithm is enabled it will tune the readings back to the correct numbers. The default “tuning speed” is however limited. This limit is application specific. In case that the ABC function is disabled (default appearance) or one cannot wait for the ABC algorithm to cure any calibration offset, two switch inputs Din1 and Din2 are defined for the operator to select one out of two prepared calibration codes.

If Din1 is shorted to ground, for a minimum time of eight (8) seconds, the internal calibration code **bCAL** (*background calibration*) is executed, in which case it is assumed that the sensor is operating in a fresh air environment (400ppm CO<sub>2</sub>).

If Din2 is shorted instead, for a minimum time of eight (8) seconds, the alternative operation code **CAL** (*zero calibration*) is executed in which case the sensor must be purged by some gas mixture free from CO<sub>2</sub> (i.e. Nitrogen or Soda Lime CO<sub>2</sub> scrubbed air). If unsuccessful, please wait at least 10 seconds before repeating the procedure again. Make sure that the sensor environment is steady and calm!

Input Switch Terminal (normally open)	Default function (when closed for minimum eight (8) seconds)
Din1	bCAL (background calibration) assuming 400ppm CO <sub>2</sub> sensor exposure
Din2	CAL (zero calibration) assuming 0ppm CO <sub>2</sub> sensor exposure

Table 2. Switch input default configurations for Senseair K33 ICB




Figure 6. Senseair K33 ICB (component side) zero and background calibration inputs for calibration jumpers.

## Technical specification (continuous operation)

Item	Senseair K33 ICB
<b>General performance</b>	
Target Gas	Carbon dioxide (CO <sub>2</sub> )
Storage Temperature Range	-40 – 70°C
Senson Life Expectancy	>15 years
Maintenance Interval	Maintenance-free when using Senseair ABC algorithm (Automatic Baseline Correction).
Self-Diagnostics	Complete function check of the sensor module
Warm-up Time	1 min
Operating Temperature Range	0 – 50°C
Operating Humidity Range	Non condensing, non-corrosive environment
Operating Environment	Residential, commercial, industrial spaces and potentially dusty air ducts used in HVAC (Heating Ventilation and Air-Conditioning) systems
<b>Electrical / Mechanical</b>	
Power Input	5 – 14VDC max rating, stabilised to within 10% (on board protection circuits) <sup>1</sup>
Current Consumption	40mA average <200mA average during IR lamp ON (120msec) <250mA peak power (during IR lamp start-up, the first 50msec)
Electrical Connections	terminals not mounted (G+, G0, OUT1, OUT2, Din1, Din2, TxD, RxD) <sup>2</sup>
Dimensions [mm]	51 x 58 x 12 (Length x Width x approximate Height)
<b>CO<sub>2</sub> measurement</b>	
Sensing Method	non-dispersive infrared (NDIR) waveguide technology with ABC (automatic background calibration algorithm)
Sampling Method	diffusion or flow, subject for discussion with customer
Response Time (T1/e)	<20s, diffusion or tube IN/OUT (0.2l/minute gas flow)
Measurement Range	0 – 30% <sub>vol.</sub>
Digital Resolution	0.001% <sub>vol.</sub>
Repeatability	±0.1% <sub>vol.</sub> CO <sub>2</sub> ±2% of measured value
Accuracy	±0.5% <sub>vol.</sub> CO <sub>2</sub> ±3% of measured value <sup>3, 4</sup>

<sup>1</sup> Notice that absolute maximum rating is 14V, so that sensor can be used with 12V±10% supply.

<sup>2</sup> Different options exist and can be customised depending on the application. Please contact Senseair for further information!

Item	Senseair K33 ICB
Pressure Dependence	+1.6% reading per kPa deviation from normal pressure, 100kPa
On-board calibration support	Din1 switch input to trigger Background Calibration @ 400ppm (0.04%vol) CO <sub>2</sub> Din2 switch input to trigger Zero Calibration @ 0ppm CO <sub>2</sub>
<b>Linear Signal Output:</b>	
OUT2	
- D/A Resolution	5mV
- Linear Conversion Range	0 – 5VDC for 0 – 20% <sub>vol</sub> .
- Electrical Characteristics	R <sub>OUT</sub> <100, R <sub>LOAD</sub> >5k, Power input >5.5V <sup>6</sup>
<b>PWM Output</b>	
Electrical Characteristics	Open collector with series 120R resistor, 10k pull-up resistor to protected power (+)
Minimum Output Concentration	0% <sub>vol</sub>
Output Cycle Period	1004ms
Output High Level max Duration	1002ms (@20% <sub>vol</sub> )
Resolution	0.5ms (@0.01% <sub>vol</sub> = 100ppm)

Table 3. Key technical specification for Senseair K33 ICB

<sup>3</sup> In normal IAQ applications. Accuracy is defined after minimum three (3) ABC periods of continuous operation. However, some industrial applications do require maintenance. Please, contact Senseair for further information!

<sup>4</sup> Accuracy is specified over operating temperature range. Specification is referenced to certified calibration mixtures. Uncertainty of calibration gas mixtures (+/-1% currently) is to be added to the specified accuracy for absolute measurements.

### Sensor PWM output timing diagram




Figure 7. Senseair K33 ICB OUT1 timing diagram.

### Gases that may affect operation of sensor

Since optical part has no reflective coating, stability of the sensor is governed by corrosion resistance of electronic assembly.

Corrosive environments containing but not limited by hydrogen sulfide, ammonia, ozone, sulphuric acid, sulfur dioxide should be avoided.

www.senseair.com



©2019 Senseair AB. All rights reserved.

Document  
PSP0141

Rev  
9

Page  
8 (8)